MRIC Equipment Cycling

Instructions

Cycle/reboot your router to fix internet issues, improve speeds, clear cache, and help keep your router protected from cyberattacks.

*Unplug the power and ethernet cables from the router.
*Wait at least 30 seconds for the router to power off completely.
*Reconnect the power and ethernet cables.
*Wait for the Internet light to turn solid, then check your internet connection.
*If you are still experiencing issues call MRIC support at +1 (720) 210-1969.